


SmokeTip®

INSTRUCTIONS

MiniSub® SubTank® SubTankXL®



1 fill

2 turn on

3 vape

Charging Insert the supplied charging cord and connect. The button color will turn red if there is less than 30% power, blue when over 30% & white when over 50% power remaining. If your unit has a digital screen, view the screen for battery status. As with any electrical device, charge on a stable fire-resistant surface clear of debris. Do not leave unattended for long periods of time. All SmokeTip units are equipped with a passthrough feature so you can vape while charging.

Adding Liquid Simply unscrew the top cap and fill along the side of the liquid tank, avoiding the center air flow tube. Please do not fill past the large center pillar (80%) to avoid leakage.

Changing the Atomizer When vapor production or flavor decreases unscrew the bottom air flow chamber and unscrew the atomizer counter clockwise & replace with a new atomizer. Once fully reassembled, place 6-8 drops of liquid into the top mouthpiece hole to "prime" the atomizer. Once the atomizer cotton is initially soaked, it is ready for continual use.

AirFlow Dial You can adjust the airflow and control vapor production by turning the air flow dial.

Drip Tip All units are equipped with a unique flavor drip tip. If you like, you can drip 4-10 drops of liquid directly through the top mouthpiece without removing it to enjoy a more robust flavor. The tank does not have to be filled with any liquid to drip.

Other

Never over tighten any components - lightly snug fit all pieces to avoid damage. All components except the atomizer and battery can be rinsed under warm water. The battery can be cleaned with a soft damp cloth and fully dried before use. For full specifications of your particular SmokeTip Vaporizer and video instructions, please visit our website.

www.SmokeTip.com



INSTRUCTIONS

HOW TO USE Your SmokeTip unit is made up of two pieces - a long white battery and an atomizer cartridge. The battery will be charged when you receive so you can begin to enjoy right out of the box! Remove a cartridge and take off the two end caps. Screw the cartridge onto the battery. For each new cartridge take a long 3-4 second drag followed by a 1-2 second drag to help start the atomizer and prep the solution - do this a few times for each new cartridge.

When the unit no longer creates a vapor, has a "burnt" taste, gets very warm, or has no flavor it may be time to change the atomizer cartridge. You should try to change the battery first, before changing the cartridge (your battery may be low if no vapor is produced). Please use caution because the cartridge can get hot when there is no solution left. Our unique cartridge design prevents leaking BUT if for some reason it does, wash your hands thoroughly.

Charging While in use, the LED on the tip of the battery will flash if the battery is low and needs recharging. Plug the wall adapter into the wall and take the white battery and screw it into the USB charger then plug into the wall adapter. The tip of the battery will blink 3 times when plugged in properly. The USB charger may also be used directly into any USB port on your computer. Charging the battery will be 2-3 hours.

Travel Charger (sold separate) Plug the USB plug (upper left hand side) into wall adapter or computer to charge the travel charger battery for 6-8 hours. The top indicator light will turn red when charging. You can use the unit to charge batteries on the road up to 3 times before recharging the unit again.

Battery or Cartridge Leaks do not touch - place in a plastic bag for replacement. As with any electronic device, prevent it from mixing with metal articles in your pocket, purse or other bags - this will damage the battery and cartridge. We do have carry cases to prevent this issue.

Ingredients water, nicotine, propylene glycol (a water-based ingredient found in many medicines & health care products), tobacco flavoring, and other ingredients for flavor. NONE of the ingredients in our cartridges have been found to be carcinogenic. Keep on Vaping!

Caution As with any electrical device, this unit should be charged on a fire-resistant surface. A bad connection may increase the risk of overheating and make the unit very hot. For issues please contact us immediately. Do not leave unattended for safety purposes.

TO ORDER SmokeTip[®] REFILLS & ACCESSORIES
www.SmokeTip.com



INSTRUCTIONS

Battery and Charging Plug the wall adapter into the wall and the USB charger into the port on the wall charger. Screw one of the batteries into the round opening on the USB charger. Charge each NEW battery 4-6 hours. The USB charger may be used by itself directly in the USB port on your computer or other USB compatible devices. In case of battery leakage or damage throw away immediately. To prevent damage, do not let your battery come in contact with other metal devices.

Using Your MiniTank® To use, simply place your thumb on the button located on the battery and keep pressed while drawing from the mouth piece. Take a long smooth drag as you would with a traditional cigarette. The battery CAN be put in "off mode" by pressing the button 6 times rapidly. This will prevent the battery from activating. Press 6 times again to place in "On Mode" again.

If any parts have been damaged, dented or scratched, you can get replacement parts on our website.

Be sure to visit our website for more instructions and troubleshooting tips



Adding Liquid Our unique design allows for easy refilling. To fill, simply unscrew the bottom of the unit and add liquid through the side of the liquid tank, avoiding the center air flow tube. Screw the tip back on snug, but do not over tighten. Do not fill past the center airflow tube.



Atomizer Instructions When the unit no longer creates a vapor, has a "burnt" taste or has no flavor it may be time to change the atomizer. Please use caution because the atomizer does get hot. To change the atomizer simply screw off the bottom piece and you will see the atomizer. Unscrew the old atomizer, and replace. Be sure not to over tighten.

Battery Options Your MiniTank[®] can be used with almost every SmokeTip[®] battery including our 15W and 40W variable batteries. We do not recommend vaping above 15 to 20watts with the MiniTank. You can purchase a conversion adapter on our website.

Caution As with any electrical device, this unit should be charged on a fire-resistant surface. A bad connection may increase the risk of overheating and make the unit very hot. For issues please contact us immediately. Do not leave unattended for safety purposes.

TO ORDER MiniTank[®] LIQUID & ACCESSORIES
www.SmokeTip.com



INSTRUCTIONS

Battery and Charging Plug the wall adapter into the wall and the USB charger into the port on the wall charger. Screw one of the batteries into the round opening on the USB charger. Charge each NEW battery 4-6 hours. The USB charger may be used by itself directly in the USB port on your computer or other USB compatible devices. In case of battery leakage or damage throw away immediately. To prevent damage, do not let your battery come in contact with other metal devices. Your SmokeTank kit comes with a "Transition" piece to use between the battery and the SmokeTank unit.

Using Your SmokeTank To use, simply place your thumb on the button located on the battery and keep pressed while drawing from the mouth piece. Take a long smooth drag as you would with a traditional cigarette. The battery CAN be put in "off mode" by pressing the button 6 times rapidly. This will prevent the battery from activating. Press 6 times again to place in "On Mode" again.

If any parts have been damaged, dented or scratched, you can get replacement parts on our website.

Be sure to visit our website for more instructions and troubleshooting tips



Adding Liquid Our unique design allows for easy refilling. To fill, simply unscrew the top of the unit and add liquid through the top side of the liquid tank, avoiding the center air flow tube. Screw the tip back on snug, but do not over tighten.



Atomizer Instructions When the unit no longer creates a vapor, has a "burnt" taste or has no flavor it may be time to change the atomizer. Please use caution because the atomizer does get hot. To change the atomizer simply screw off the bottom piece and you will see the atomizer. Unscrew the old atomizer, and replace. Be sure not to over tighten.

Adjustable Airflow On the bottom of your SmokeTank unit you will see an air flow dial that you can adjust to 4 different settings. Simply turn the dial to your preference.

Flavor Boost Your SmokeTank® vaporizer is equipped with a unique "flavor boost" tip that sends liquid directly to the atomizer. This will create an increase in flavor and vapor. Simply press down the tip 1-5 times to create this unique experience. It is not recommended to press more than 5 times per 20 puffs. Although it is not necessary, many find this feature enjoyable. Also, if you are just adding liquid to your tank, this will prime the atomizer for immediate use!

TO ORDER SmokeTank® LIQUID & ACCESSORIES
www.SmokeTip.com



INSTRUCTIONS

Battery and Charging Your SmokeTankXL® battery comes with a micro USB cord and a wall adapter. The USB charger may be used by itself directly in the USB port on your computer or other USB compatible devices. Simply plug the micro usb cord into your battery, then the USB plug into the wall adapter, then into the wall. The indicator screen will let you know battery status.

The battery CAN be put in "off mode" while traveling by pressing the button 5 times rapidly. This will prevent the battery from activating. Press 5 times again to place in "On Mode" again. The battery will "sleep" after 20 minutes of inactive use. The battery will also shut down if power button is pressed for more than 10 seconds. To prevent damage, do not let your battery come in contact with other metal devices.

Your battery will also let you know if there is a problem with the atomizer, if the unit is getting too hot, if you have the watts set too high or if the battery is running too low to operate. Please change or reattach an atomizer if you receive atomizer warning messages.

Our 40W variable battery allows you to select between 7 to 40 watts by turning the chrome dial to the left or right. You will notice an increase in vapor and flavor as you increase the wattage.



Adding Liquid To fill, simply unscrew the bottom of the unit and add liquid through the side of the liquid tank, avoiding the center air flow tube. Screw the bottom back on snug, but do not over tighten. Do not fill past the center air flow tube. After filling or changing your atomizer please wait at least 2 minutes to allow time for the liquid to absorb into the atomizer.



Using Your SmokeTankXL® To use, screw the vaporizer onto the battery, place your thumb on the button located on the battery and keep pressed while drawing from the mouth piece.

Atomizer Instructions When the unit no longer creates a vapor, has a "burnt" taste or has no flavor it may be time to change the atomizer. Please use caution because the atomizer does get hot. To change the atomizer simply screw off the bottom piece and you will see the atomizer. Unscrew the old atomizer, and replace. Be sure not to over tighten. To prime, you can place a few drops of liquid along the inner wall (white cap) inside the atomizer, before screwing on to the vaporizer.

Adjustable Airflow On the bottom of the unit you will see an air flow dial that you can adjust to over 20 different settings. Simply turn the dial to your preference.

TO ORDER SmokeTankXL® LIQUID & ACCESSORIES
www.SmokeTip.com



INSTRUCTIONS

Battery and Charging Your MegaTank® battery comes with a micro USB cord and a wall adapter. The USB charger may be used by itself directly in the USB port on your computer or other USB compatible devices. Simply plug the micro usb cord into your battery, then the USB plug into the wall adapter, then into the wall. The indicator screen will let you know battery status.

The battery CAN be put in "off mode" while traveling by pressing the button 5 times rapidly. This will prevent the battery from activating. Press 5 times again to place in "On Mode" again. The battery will "sleep" after 20 minutes of inactive use. The battery will also shut down if power button is pressed for more than 10 seconds. To prevent damage, do not let your battery come in contact with other metal devices.

Your battery will also let you know if there is a problem with the atomizer, if the unit is getting too hot, if you have the watts set too high or if the battery is running too low to operate. Please change or reattach an atomizer if you receive atomizer warning messages.

Our 40W variable battery allows you to select between 7 to 40watts by turning the chrome dial to the left or right. You will notice an increase in vapor and flavor as you increase the wattage.



Adding Liquid To fill, simply unscrew the bottom of the unit and add liquid through the side of the liquid tank, avoiding the center air flow tube. Screw the bottom back on snug, but do not over tighten. Do not fill past the center air flow tube. After filling or changing your atomizer please wait at least 2 minutes to allow time for the liquid to absorb into the atomizer.



Using Your MegaTank® To use, screw the vaporizer onto the battery, place your thumb on the button located on the battery and keep pressed while drawing from the mouth piece.

Atomizer Instructions When the unit no longer creates a vapor, has a "burnt" taste or has no flavor it may be time to change the atomizer. Please use caution because the atomizer does get hot. To change the atomizer simply screw off the bottom piece and you will see the atomizer. Unscrew the old atomizer, and replace. Be sure not to over tighten. To prime, you can place a few drops of liquid along the inner wall (white cap) inside the atomizer, before screwing on to the vaporizer.

Adjustable Airflow On the bottom of the unit you will see an air flow dial that you can adjust to over 25 different settings. Simply turn the dial to your preference.

TO ORDER MegaTank® LIQUID & ACCESSORIES
www.SmokeTip.com



INSTRUCTIONS

40W Variable Wood Battery

Charging Your SmokeTip 40W Variable Wood Battery comes with 2 batteries and a wall charger. To charge the batteries place them into the charger then into the wall. The light will turn from red to green when they are fully charged.

Use screw the bottom cap off the battery compartment and place the battery into the unit positive side first then screw the cap back on. Connect your vaporizer to the unit at the top. To turn the unit on, press the large chrome button 5 times - you will see the display light up. Your unit is now ready to use. Simply press and hold the large chrome button and draw.

Functions You can increase or decrease your wattage by pressing the small buttons above the main power button. The recommended setting is generally 25W but increase or decrease to suit your taste. If you notice a "burnt" taste we recommend decreasing the power.

Features By pressing the “+” and “-” buttons at the same time for 2 seconds you can enter the settings feature:

1. **Display** you can choose what is displayed on the LCD screen while vaping. You can display the puff count, resistance, current or smoke time.
2. **Screen** here you can choose to turn the display screen on or off.
3. **Mobile** if you have an adapter for the top of the unit to charge your phone battery you can change this to “On” and use the Wood Battery as a backup charger for your phone.
4. **Settings** in this section you can choose the vaping time to manual or automatic. You can also clear the times and puffs counts or restore your battery to factory settings if you are having issues.

Cleaning wipe with a slightly damp cloth and dry.

As with **any** electrical device, this unit should be charged on a fire-resistant surface. A bad connection may increase the risk of overheating and make the unit very hot. For issues please contact us immediately. Do not leave charging unattended for long periods of time. (not more than 48 hours is recommended).

TO ORDER LIQUID & ACCESSORIES
www.SmokeTip.com



40W Variable Battery

INSTRUCTIONS

SmokeTip's 40w variable battery comes with a micro USB cord and a wall adapter. The USB charger may be used by itself directly in the USB port on your computer or other USB compatible devices. Simply plug the micro usb cord into your battery, then the USB plug into the wall adapter, then into the wall. The indicator screen will let you know battery status.

The battery CAN be put in "off mode" while traveling by pressing the button 5 times rapidly. This will prevent the battery from activating. Press 5 times again to place in "On Mode" again. The battery will "sleep" after 20 minutes of inactive use. The battery will also shut down if power button is pressed for more than 10 seconds. To prevent damage, do not let your battery come in contact with other metal devices.

Your battery will also let you know if there is a problem with the atomizer, if the unit is getting too hot, if you have the watts set too high or if the battery is running too low to operate. Please change or reattach an atomizer if you receive atomizer warning messages.

Our 40W variable battery allows you to select between 7 to 40watts by turning the chrome dial to the left or right. You will notice an increase in vapor and flavor as you increase the wattage.

Cleaning wipe with a slightly damp cloth and dry.

As with **any** electrical device, this unit should be charged on a fire-resistant surface. A bad connection may increase the risk of overheating and make the unit very hot. For issues please contact us immediately. Do not leave charging unattended for long periods of time. (not more than 48 hours is recommended).

TO ORDER LIQUID & ACCESSORIES
www.SmokeTip.com